
COMPUTER CONTROLLED SYSTEM
106
110
MEMORY
CODE
122
108
MICROCONTROLLER
120
CARD READER
112
COMPUTER CONTROLLED DEVICE
102
128
126
118
MEMORY UNIT
CODE
124
MEMORY CONTROLLER
116
114
104
100

FIG. 1


200
PLACE CARD IN RESET MODE
206
APPLY CARD IDENTIFICATION SIGNAL
208
202
MONITOR RESPONSE
210
212
MEMORY CARD ?
NO
STOP
214
YES
ACTIVATE NRSS INTERFACE - APPLY CLOCK - RECEIVE DATA
216
ANALYZE A HEADER
REJECT DATA
204
218
220
SEND DATA TO MEMORY
222
STOP
224

FIG. 2